

Major Assemblies, Top

Ref.Desig.	Option	Part Number	Qty	Description
A1, A2				NOT SHOWN (see “Front Panel Assembly, Inside” on page 13-20)
A3		08753-60232	1	ASSEMBLY-SOURCE 3 GHz (EXCHANGE: 08753-69232)
A3	006	08753-60230	1	ASSEMBLY-SOURCE 6 GHz (EXCHANGE: 08753-69230)
A4		08753-60951	1	ASSEMBLY-SAMPLER R
A5		08753-60951	1	ASSEMBLY-SAMPLER A
A6		08753-60951	1	ASSEMBLY-SAMPLER B
A7		08753-60164	1	BOARD ASSEMBLY-PULSE GENERATOR
A8 ^a		08753-60949	1	BOARD ASSEMBLY-POST REGULATOR
A10		08753-60958	1	BOARD ASSEMBLY-DIGITAL IF
A11		08753-60162	1	BOARD ASSEMBLY-PHASE LOCK
A12		08753-60957	1	BOARD ASSEMBLY-REFERENCE
A13		08753-60013	1	BOARD ASSEMBLY-FRAC N ANALOG
A14		08753-60068	1	BOARD ASSEMBLY-FRAC N DIGITAL
A15		0950-3488	1	ASSEMBLY-PREREGULATOR
A16, B1				NOT SHOWN (see “Rear Panel Assembly” on page 13-22)
A17				NOT SHOWN (see “Chassis Parts, Inside” on page 13-36)
A18, A27, RPG			1	NOT SHOWN (see “Front Panel Assembly, Inside” on page 13-20)
A19		08753-60359	1	BOARD ASSEMBLY-GRAPH. PROCESSOR (GSP) (under sheet metal cover)
A20		0950-2782	1	ASSEMBLY-DISK DRIVE
A26	1D5			NOT SHOWN (see “Rear Panel Assembly, Option 1D5” on page 13-24)

a. For fuse part numbers for the A8 board, refer to [“Miscellaneous”](#) on page 13-37.